



### CX-WEC SERIES: EMERGENCY CALL SYSTEMS FOR UNIVERSAL RESTROOMS



Listed Components



Compliant

*CX-WEC Series are equipment packages designed to meet the latest building code requirements for universal restrooms. Emergency Call Systems may be installed in restrooms without an automatic door operator, or with Camden CX-WC Series barrier-free restroom kits (with operator).*

### Specifications

Current Draw: CX-WEC Series: 165mA

MODELS		List Price
CX-WEC10	<b>UNIVERSAL EMERGENCY CALL KIT</b>	
	(1) <b>CM-450R/12</b> Single gang mushroom push button, stainless steel faceplate, push/pull, 'PRESS FOR EMERGENCY ASSISTANCE'	
	(1) <b>CM-AF50150</b> Single gang LED annunciator with adjustable sounder 'ASSISTANCE REQUESTED'	
	(1) <b>CM-AF14150</b> Single gang LED dome light with sounder	
CX-WEC10K2	(1) <b>CM-SE21</b> English, solid white sign, 'IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE'	
	Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	
	<b>UNIVERSAL EMERGENCY CALL KIT</b>	
	(1) <b>CM-AF54050</b> Double gang, push/pull red mushroom push button, 'Assistance Required', with LED annunciator & adjustable sounder, 'Assistance Requested'	
CX-WEC10BK2	(1) <b>CM-AF14150</b> Single gang LED dome light with sounder	
	(1) <b>CM-SE21</b> English, solid white sign, 'IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE'	
	Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	
	<b>UNIVERSAL EMERGENCY CALL SYSTEM KIT, WITH MULTI-COLOR DOME LIGHT</b>	
CX-WEC10CK2	(1) <b>CM-AF54050</b> Double gang, push/pull red mushroom push button, 'Assistance Required', with LED annunciator & adjustable sounder, 'Assistance Requested'	
	(1) <b>CM-AF14150</b> Single gang LED dome light with sounder	
	(1) <b>CM-SE21</b> English, solid white 'EMERGENCY' sign	
	Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	
CX-WEC10CK2	<b>EMERGENCY CALL SYSTEM KIT-2 DOOR RESTROOMS, MULTI-COLOR DOME LIGHT</b>	
	(1) <b>CM-AF54050</b> Double gang, push/pull red mushroom push button, 'Assistance Required', with LED annunciator & adjustable sounder, 'Assistance Requested'	
	(2) <b>CM-AF14250</b> Single gang multi-Color LED dome light with sounder	
	(1) <b>CM-SE21</b> English, solid white 'EMERGENCY' sign	
CX-WEC10CK2	Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	

IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE



CX-WEC10

IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE



CX-WEC10K2

IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE



CX-WEC10BK2

IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE



CX-WEC10CK2



# RESTROOM CONTROL KITS

## DOOR CONTROL

### CX-WEC SERIES: EMERGENCY CALL SYSTEMS FOR UNIVERSAL RESTROOMS

MODELS		List Price
CX-WEC12	<b>UNIVERSAL EMERGENCY CALL KIT, WITH PUSH BUTTON RESET</b> (1) <b>CM-AF501SO</b> Single gang LED annunciator w/ adjustable sounder 'ASSISTANCE REQUESTED' (1) <b>CM-AF141SO</b> Single gang LED dome light with sounder (1) <b>CM-SE21</b> English, solid white 'EMERGENCY' sign (1) <b>CM-LRS24</b> 24V latching relay assembly for EM Call system using momentary 'Press For Emergency Assistance' switches (1) <b>CM-8010R/13</b> Momentary, 'Press for Reset' 1" red push button; for use with momentary 'Press For Emergency Assistance' switches (extra) Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	\$563.00
	<b>EMERGENCY CALL SYSTEM KIT WITH RIBBON SWITCH AND PUSH BUTTON RESET</b> (1) <b>CM-AF501SO</b> Single gang LED annunciator w/ adjustable sounder 'ASSISTANCE REQUESTED' (1) <b>CM-AF141SO</b> Single gang LED dome light with sounder (1) <b>CM-SE21</b> English, solid white 'EMERGENCY' sign (1) <b>CM-LRS24</b> 24V latching relay assembly for EM call system using momentary 'Press For Emergency Assistance' switches (1) <b>CM-8010R/13</b> Momentary, 'Press for Reset' 1" red push button; for use with momentary 'Press For Emergency Assistance' switches (extra) (1) <b>60-68B010</b> Ribbon switch, 33.5" vertical, "Press For Emergency Assistance" red lettering on white background Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	\$900.00
CX-WEC13	<b>UNIVERSAL EMERGENCY CALL KIT, WITH KEY SWITCH RESET</b> (1) <b>CM-AF501SO</b> Single gang LED annunciator w/ adjustable sounder 'ASSISTANCE REQUESTED' (1) <b>CM-AF141SO</b> Single gang LED dome light with sounder (1) <b>CM-SE21</b> English, solid white 'EMERGENCY' sign (1) <b>CM-LRS24</b> 24V latching relay assembly for EM call system using momentary 'Press For Emergency Assistance' switches (1) <b>CM-1205/14-60KD</b> Key switch, single gang SS, SPST momentary, NC, with 'WC System Reset' text and CM-1000/60KD mortise cylinder, keyed different; for use with momentary 'Press For Emergency Assistance' switches (extra) Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	\$619.00
	<b>UNIVERSAL EMERGENCY CALL SYSTEM KIT WITH RIBBON SWITCH AND RESET KEY SWITCH</b> (1) <b>CM-AF501SO</b> Single gang LED annunciator w/ adjustable sounder 'ASSISTANCE REQUESTED' (1) <b>CM-AF141SO</b> Single gang LED dome light with sounder (1) <b>CM-SE21</b> English, solid white 'EMERGENCY' sign (1) <b>CM-LRS24</b> 24V latching relay assembly for EM call system using momentary 'Press For Emergency Assistance' switches (1) <b>CM-1205/14-60KD</b> Key switch, single gang SS, SPST momentary, NC, with 'WC System Reset' text and CM-1000/60KD mortise cylinder, keyed different; for use with momentary 'Press For Emergency Assistance' switches (extra) (1) <b>60-68B010</b> Ribbon switch, 33.5" vertical, "Press For Emergency Assistance" red lettering on white background Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	\$1000.00





## DOOR CONTROL

### CX-WEC SERIES: EMERGENCY CALL SYSTEMS FOR UNIVERSAL RESTROOMS

EMERGENCY CALL - COMPONENTS		List Price
CM-450R/12	Single gang mushroom push button, stainless steel faceplate, push/pull, 'PRESS FOR EMERGENCY ASSISTANCE'. For extra contacts to connect additional notification devices or systems, order CM-4000/60N (N/O) or CM-4000/61N (N/C)	\$160.00
CM-450R/12FE	Bilingual single gang mushroom push button, stainless steel faceplate, push/pull, 'PRESS FOR EMERGENCY ASSISTANCE' and French language sign, laser etched with brushed stainless finish	\$172.00
CM-AF501SO	Single gang LED annunciator with adjustable sounder, 'ASSISTANCE REQUESTED'	\$200.00
CM-AF540SO	Double gang, stainless steel faceplate, push/pull red mushroom push button, 'ASSISTANCE REQUIRED' with LED annunciator and adjustable sounder, 'ASSISTANCE REQUESTED'. Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	\$362.00
CM-AF141SO	Single gang LED dome light with adjustable sounder Add suffix 'F' for French, 'FE' for French/English, 'SP' for Spanish	\$210.00
CM-AF142SO	Single gang multi-color LED dome light with sounder selectable red, green, blue or white	\$231.00
CX-LRS12	12V latching relay assembly for EM call system using momentary 'PRESS FOR EMERGENCY ASSISTANCE' switches	\$189.00
CX-LRS24	24V latching relay assembly for EM Call system using momentary 'PRESS FOR EMERGENCY ASSISTANCE' switches	\$189.00
CM-1205/14-60KD	Single gang stainless steel key switch, SPST momentary, NC, with 'WC System Reset' text and CM-1000/60KD mortise cylinder, keyed different	\$214.00
CM-8010R/13	Vandal resistant 1" red push button, single gang aluminum, N/C momentary with 'PRESS TO RESET' text	\$144.00
60-60B010	Ribbon switch, 33.5" vertical, "Press For Emergency Assistance" red lettering on white background	\$375.00
EMERGENCY CALL - SIGNAGE		List Price
CM-SE21	English, solid white sign, 12.5" x 8.5" (317.5mm x 216mm) 'IN THE EVENT OF AN EMERGENCY PUSH EMERGENCY BUTTON AND AUDIBLE AND VISUAL SIGNAL WILL ACTIVATE'	\$46.00
CM-SE21F	French, solid white sign, 12.5" x 8.5" (317.5mm x 216mm) 'DANS LE CAS D'UNE URGENCE POUSSER LE BOUTON D'URGENCE POUR ACTIVER LE SIGNAL SONORE ET VISUEL'	\$40.00



CM-450R/12




CM-AF501SO



CM-AF540SO



CM-AF141SO



CM-AF142SO



CM-LRS12



CM-1205/14-60KD



CM-8010R/13



60-60B010

**IN THE EVENT  
OF AN EMERGENCY  
PUSH EMERGENCY  
BUTTON AND AUDIBLE  
AND VISUAL SIGNAL  
WILL ACTIVATE**

CM-SE21

**DANS LE CAS D'UNE  
URGENCE POUSSER  
LE BOUTON  
D'URGENCE POUR  
ACTIVER LE SIGNAL  
SONORE ET VISUEL**

CM-SE21F