


Notes	1. CX-33 can be set to Mode 7 (Normally Unlocked) or Mode 8 (Normally Locked).
	2. Mode 7 = Set Strike to Fail Safe.
	3. Mode 8 = Set Strike to Fail Secure.

NOTE: This Drawing should be used in addition to each products respective Installation Manual.
(not in place of)



		2395 Skymark Ave. Mississauga, ON L4W 4Y6	
SCALE: NONE	DRAWN BY: JML (JF)	DATE: Sept 2, 2026	REV: 2
CX-WC17 Wiring Diagram (Normally Unlocked)			
DRAWING No: DRG-CX-WC17-7		FILENAME: CX-WC17-7_Wiring Diagram_R2.ai	